AUTEL®

IM608 CONNECTION

USING THE XP400 AND J2534 TO PERFORM KEY PROGRAMMING

DO NOT CONNECT THE XP400 TO THE VEHICLE DIRECTLY

VEHICLE CONNECTION

✗ THIS CONNECTION MAY DAMAGE THE XP400 MAIN BOARD

VEHICLE CONNECTION

DO NOT connect the XP400 to the vehicle directly. The DB26-PIN port is to connect with the Mercedes Benz infrared cable, vehicle key cable, ECU cable, MCU cable, or MC9S12 cable.

Use J2534 JVCI the for vehicle connection with the main cable. the J2534 can be connected to the IM608 via Bluetooth or USB cable.

AUTEL®